




CAMERA SCANNER

Instruction Manual

Confirm the attached


☐ Camera Scanner




☐ USB Cable



☐ Software (Optional)



☐ Text Positioning Pad




☐ Instruction Manual



☐ Hand Button




☐ Foot Pedal(Optional)




Device connection

Connect the attached USB cable to PC, and then operate in the software.



► Product Preview

1. LED Touch Switch
2. Camera Lens
3. LED Light
4. Weighted Base



Software installation

► Online Download

Link to the website:

<https://www.joyusing.com/download-bookscanner.html>


Choose the software.




Start to operate



When scanning with your fingers to fasten the document, please make sure your fingers are put at the mid of two sides of a document.



Finger placement area



Notice

1. When scanning with your fingers to fasten the book, please make sure your fingers are put at the mid of two sides of a book.
2. Please make sure you are not scanning books in a circumstance with strong light, as there will be light interference to the laser, and weaken the scanning performance.
3. Please adjust the auxiliary lighting to get better scanning results when the ambient light is not strong enough.
4. Please don't move the document or turn pages while scanning it will influence the scanning result.

After-sale service

Warranty Card

Address: _____

Email: _____

Zip Code: _____

Date of Purchase: _____

Number of Invoice: _____

Qualification
Certificate

QC _____