





V1X-4K

Document Camera User Manual

1. Package list


☐ Document Camera




☐ Remote Control




☐ USB2.0 Cable



☐ HDMI Cable



☐ DC Adapter (12V1A)




☐ Soft Pad






☐ User Manual



2. Remote control and interface instruction



- | | |
|------------------|-------------------------------------|
| 1. IR Receiver | 8. VGA_OUT |
| 2. Camera Lens | 9. USB(PC&Flash drive) |
| 3. LED Light | 10. USB(Mouse, touch control, etc.) |
| 4. Stepless knob | 11. LINE IN |
| 5. HDMI_IN | 12. LINE OUT |
| 6. HDMI_OUT | 13. POWER |
| 7. VGA_IN | |



- | | |
|---|--|
|  Menu |  Record a video clip |
|  LED Light on/off |  Capture a still image |
|  Change to HDMI/VGA |  Change the resolution/back to main menu |
|  Freeze image |  Press to realize the function/auto focus |
|  Rotate image |  Power on/off |


3. Software download



4. Device connection

PC Connection


- 1.Plug in the power adapter to the power socket and Document Camera.
- 2.Connect the USB cable to the PC and Document Camera.
- 3.Install the software.







- ★ **Compatible with Mac/Chrome/Windows XP and above**
- ★ **Software download:**
<https://www.joyusing.com/download.html>
- ★ **Detailed Instructions:**
<https://www.joyusing.com/download.html>

PC-free

- 1.Plug in the power adapter to power socket and Document Camera.
- 2.Connect the HDMI/VGA cable to the Document Camera and Touch screen.
- 3.Connect the USB cable to the Document Camera and Touch screen (touch usb port).



Document Camera and external equipment connections as below:

Document Camera Interface	Connection Cable	External Equipment Interface
 HDMI_OUT		 HDMI_IN
 HDMI_IN		 HDMI_OUT
 VGA_OUT		 VGA_IN
 VGA_IN		 VGA_OUT

5. Attention



Before use:

- Do not leave it under direct sunlight or by heaters. It maybe discolored or damaged.
- Do not place this product in any humid, dusty, or vibrating locations.
- Carry the product by holding the base in both hands. Never hold the product by the arm or the camera head.
- Use a soft, dry cloth for cleaning instead of any volatile solvent.
- When the device is not in use for a while, please turn off the power.
- Fold the arm when the product will not be used for a long time.

During use:

- Please prevent children from operating the device without supervision.
- Recommended environmental conditions: Temperature: 0°C - 40°C (32°F - 104°F) .
- Humidity: 30% - 85% (No condensation) .
- Use the product on a stable base, desk, or table.
- Do not turn or flip the camera head or arm to its limitation as below manual instructs.
- Do not point the camera lens directly at the sunlight. It may be damaged and fails to image.
- Do not look directly to the LED lamps to prevent your eyes from being damaged.
- The product may not be operated properly if a USB hub is used to connect the product and a PC.
- Be careful to prevent the unit from dropping or overturning
- Please prevent the camera head to hit the desk top or any other hard objects, or it can be damaged easily.

Precautions for operation



Note:

Do not grasp the the lens, arm or joints when picking up the device. Please use both hands to hold the bottom of the device. Handling the device improperly may cause mechanical malfunctions.

Warranty card

Model _____

Add _____

Tel _____

E-mail _____

Date _____

Certification

Model _____

Insrptor No. _____

Production date _____

Manufacturer Joyusing Technology Co., Ltd.



Joyusing Technology Co., Ltd.

Website: www.joyusing.com

Tel: 0086-591-86399086

Email: sales@joyusing.com

Address: No.27 Yangzhou Road Cangshan District, Fuzhou, Fujian, China